



Base Frame - 49" 2x4 / 48"x48" 1/2" Plywood

□ =2"




4x4 Columns - 41-1/2" 4x4

 =2"



Side Panels - 42-1/4" x 39-1/2" 3/4" Plywood

= 2"



1)

Paint the external sides of the Side Panels

2)


See "4x4 Columns," Diagram #3, on setting the Columns in place.
The Side Panels should extend approx. 3/4" above the 4x4 Columns.

Top Frame - 44-3/4" 2x4

 =2"


1)

Route the exact center of the 44-3/4" 2x4 with a 1" square router bit, 7/8" deep.




2)

keeping the 2x4's centered on the top of the Side Panels, at all times, align the outside corner edge of both 2x4's. if they do not, align perfectly, adjust the length of the 2x4's as necessary.



44-3/4"


3)



Blow-up of Eye-Hook Placement


 =1/2"

4)



Lid - 45" 1x2 / 46-1/2" 1x2 / 46-1/2"x46-1/2" 1/2" Ply.

□ = 2"



1)

Join Frame Together with 1-1/2" nails at corners from the outside edge of the 46-1/2" 1x2's.

2)

Then attach Lid frame to Plywood Panel with wood glue and 1-1/2" nails from top of Lid.

Paint entire assembly.

Add Handles.

